

Smart Kit Storage and Maintenance

Prior to storing the smart kit please follow the procedure below:

- 1. Remove the chemical cap from the chemical bottle
- 2. Fill a small clean bucket with warm or hot water (140 F MAX)
- 3. Put the Smart Kit into the pre-spray position
- 4. Turn the pump for the machine on
- 5. Pull the trigger on the pre-spray gun while holding the chemical cap in the bucket of water
- 6. Continue to run like this for approximately 30 45 seconds. You should not see any chemical left in the chemical draw line at this point.

This procedure removes any chance of chemical hardening in the injector and blocking it and will ensure continued use of your Smart Kit.